

Dial-In Server

for Nexus Communicator 2.0 Software

Includes E-Mail & Paging Features

1.0

Key Features Include

- Alarm & Event Notification
- Outage Reporting
- Email/Paging Notification
- Notify Multiple Users of Remote Problem Conditions
- Real Time Alarm Server Notification
- Retrieval of Data Trending & Storage
- Answer Remote Meters in the Field
- Automated Speech Output
- Compatible with Nexus Series Meters


Description

The Nexus Communicator Dial-In Server receives dial-in strings from remote meters in the field. It displays alarms, interrogates the meter, downloads logs and sends critical messages. Advanced e-mailing and paging informs appropriate people immediately upon events occurring.

Alarm Server

The Dial-In Server receives calls from any remote meter and displays these warnings with both visual and audible alerts:

- Alarm & Event Notification
- Audible Alarms
- Speech Alarms
- Acknowledgements
- Meter Communication Failure



Dialing-In/ Dial-Out Settings

The software enables you to dial in or it dials out to notify you instantly of any changes in power or meter functions including:

- CBEMA Power Quality Event
- High Speed Input Change
- Waveform Record Capture
- Filling of Meter Memory
- Meter Communication Failure
- Control Output Change



Email/ Paging Feature


Once the software detects a call, Nexus Communicator launches the Dial-Out feature, immediately alerting those designated users via:

- E-Mail (PC, PDA, Cell Phone)
- Pager
- Many Users can be Contacted Simultaneously



Modem Monitor

The Modem Monitor checks the PC for connected modems and monitors available modems for incoming calls. When an incoming call from a meter is detected, the Modem Monitor automatically starts the Communicator software to answer the call and process it.

Modem Monitor automatically configures the server by taking an inventory of available modems and listening to dial-in commands. This eliminates complex user configuration making the system quick to set up and easy to use.



Visual Alarm Server



Dial-In Settings

Dial Out on any Event

Ordering Information

NXDS 1.0C: Dial-In Server Single-Computer License/Single Site

NXDS 1.0MC: Dial-In Server Multi-Computer License/Single Site



Electro Industries/GaugeTech

1800 Shames Drive • Westbury, NY 11590

1-877-EIMETER (1-877-346-3837) • E-Mail: sales@electroind.com

Tel: 516-334-0870 • Web Site: www.electroind.com • Fax: 516-338-4741