Electro Industries

EI-MSB10-400 Surge Protector

PROTECTS CRITICAL SUBSTATION EQUIPMENT



Description

The EI-MSB10-400 has been designed specifically to protect substation equipment from dangerous spikes and transients. It absorbs the event utilizing a multi-stage transient suppression scheme, before critical equipment is reached. This unit is very low cost and is essential to significantly improve equipment reliability. The EI-MSB10-400 is connected by wires in parallel with the network to be protected. It can be mounted easily on a wall or plate with self-adhesive tape. See the back of this page for installation instructions.

General Application

The EI-MSB10-400 surge protector is designed to protect sensitive equipment from the damaging effects of lightning strikes and/or industrial switching surges in single phase AC networks up to 320 V AC (L-N/L-G), and DC networks up to 400 V DC.

Features

- Designed to protect critical substation equipment from damaging transients.
- Utilizes a multi-stage protection scheme designed to improve equipment reliability by shunting and absorbing dangerous spikes and surges before they reach the electronics of the installed equipment.
- Use for protection of relays, meters, panel alarms, or any other critical equipment.
- Fully compliant with IEC 61643-1 and EN 61643-11, Class 2 or Class 3 Test.
- Internal Thermal Fusing see figure on back.
- Designed to show when unit needs replacement.
- The EI-MSB10-400 has an LED to provide a replacement alert:
 - When the LED is on, the EI-MSB10-400 is in normal operation and is providing surge protection.
 - When the LED is off, the EI-MSB10-400 needs to be replaced.





Installation

- Confirm Power Service Compare voltage measurements of your system to the line voltage (L-N or L-G) listed on the product label.
- Disconnect Power Turn off all power supplying the distribution panel or meter before installing the EI-MSB10-400.
- Mount Protector Flanges are provided to mount the EI-MSB10-400
 to a flat surface. Install the EI-MSB10-400 at the electrical switchboard or
 electrical meter, downstream of the main circuit breaker, as close as possible
 to the protected device. A 20 A time delay fuse or circuit breaker should be
 used to provide over-current protection for each phase conductor.
- Wire to Service Panel Connect leads of the EI-MSB10-400 to the corresponding electrical terminal lug as follows:
 - Red Conductor (Phase/Neutral).
 - Blue Conductor (Phase/Neutral).
 - Green/Yellow Conductor (Ground).
- **Restore Power** Confirm Green LED is lit. The EI-MSB10-400 is properly installed and protection is present.

Earth Grounding Connection

The green/yellow earth conductor must be connected to the grounding system of the facility by the most direct path, and in accordance with national and local electrical codes.

Maintenance

EI-MSB10-400 Surge Protectors are maintenance free. The unit automatically resets after each transient event. If the EI-MSB10-400 sustains internal damage due to a catastrophic surge or long duration overvoltage:

- The internal fuse will open and the EI-MSB10-400 will safely disconnect itself from the power line.
- The green LED will be off, indicating the EI-MSB10-400 must be replaced.

EI-MSB10-400 Circuit Diagram





Specifications and Ordering Information	
AC Operational Voltage Max	320 V AC
DC Operational Voltage Max.	400 V DC
Clamping Voltage	1.5 kV
Discharge Current (15 times - 8/20µs)	3 kA
Discharge Current Max	10 kA
Model Number	EI-MSB10-400

1800 Shames Drive Westbury, NY, 11590 1-877-EIMETER (1-877-346-3837) Tel: 516-334-0870 Fax: 516-338-4741 Email: EIG_sales@hubbell.com Website: www.electroind.com



